

## VIN ETCHING CREAM OPERATION INSTRUCTIONS

Step 1: Wear the Hand Gloves and Face mask, before starting any etching activity.

Step 2: Clean the area of vehicle window where you want to VIN etch with the help of cleaning agent

- Step 3: Secure the stencil to the glass

- Step 4: With Fingertips, gently "pat" the stencil to remove all air bubbles and ensure that it is in full contact with glass also you can apply firm pressure with a paper towel

Step 5: The same way take the VIN cream on Fingertips, gently "pat" on the stencil area where VIN number is printed.

Step 6: once patting is over wait for 2 minutes and then remove the stencil from the glass.

Step 7: Discard the fingertip cream and clean the etched area and stencil with the help of Cleaning agent,

- Step 8: Dry and Clean the Vin Etched area with the help of Paper Towel.

- Step 9: Check you VIN number is reprinted on the window glass.

Step 10: Apply the Warning Decals from inside on both the driver's side and passengers window.

Step 11: Complete the EtchON Certificate.

-:Note:-

1. Avoid VIN etching in very hot whether or direct sunlight
2. Avoid VIN etching on wet or windy days.
3. You may use acrylic paint to have more visibility in vin etched area.

-:Safety Notes:-

1. Wear safety glasses and rubber gloves at all times during both the frosting preparation and operation.
2. In case of contacting with skin or eyes, wash immediately with running water for 5-15 minutes. Then seek medical attention if discomfort still persists.